

AERO SPORT CONCEPTS

ZL1 - FRONT SPLITTER EXTENSION KIT INSTALLATION INSTRUCTIONS

1. Jack Front of Car up and place Jack Stands under car for Safety
2. Remove all OE Screws that hold on Splitter front
3. Place Aero Extension Plate up against bottom of OEM Splitter and align all edges until edges are equal distance from either side.
4. Support Extension Plate in place with jack or other type of prop.
5. Screw Extension Plate on with OE Screws & Washer leaving them loose until all screws are located in each position
6. Once all screws are in position tighten down screws at each position

SIDE ROCKER EXTENSION KIT INSTALLATION INSTRUCTIONS

1. Jack Side of Car up and place Jack Stands under car for Safety
2. Place Aero Extension Plate up against bottom of OEM Rocker and align all edges until edges are equal distance from either side.
3. Support Extension Plate in place with jack or other type of prop.
4. Drill a 5/16" hole at each Fastener location will supplied drill bit, being very careful to not drill to deep drilling completely through Splitter. Take your time and drill slowly. Also be careful to not move the Extension as you are drilling hole
5. Once you have 3-4 holes drilled at alternating corners, insert Fasteners and tighten screws to hold Extension in place.
6. Complete drilling the rest of the holes and insert Fasteners and tighten screws.

[Visit our Facebook Page for more details and video](#)